

INSTALLATION INSTRUCTIONS

MODEL - MC4

DESCRIPTION

The 4 way group controller MC4 allows up to 4 motors to be controlled from a single control point, ie remote control, rocker or key switch. It also allows for individual control of each motor.

INSTALLATION

Connection details are shown below, ensure suitably rated cable is used when wiring.

Please note that the L terminal for the Master Control is a Live out feed to be connected to the common of the master switch, it is not used when using a remote control unit as the master control.

If using a remote control other than those shown below ensure that the up and down outputs from the remote control unit are live and **not neutral**.

The motors can be individually controlled, by connecting a switch as shown, the switch should be a 230V ac, 2 pole rocker or key switch with a suitable current rating (typically 16A).

NOTE: The individual motor control switches will not function if an UP or DOWN live input is present at the master control terminals.

