



* Swap brown and black wires if motor direction does not correspond to open and close on the rocker switch